MANUFACTURING TOLERANCES (STEEL & ALUMINUM)

All dimensions given are maximum permissable tolerances

Overall Dimensions and Squareness



D andD' are overall diagnol dimensions. W and W' are overall lengths of cross bars at opposite ends of panel.

Longitudinal Bow



Traverse Bow

(before fastening to supports)



Cross Bar Allignment and Spacing



Bearing Bar Lean